



**20i-T / 30i-T
20i-T B / 30i-T B**

Installation/Operation Manual

Manual code: 14460054

Manual version: 2302

Software version: 4.xx



INDEX

1	DRO description	3
1.1	Front panel	3
1.2	Turning the unit on and off	4
2	DRO operation	5
2.1	Display modes	5
2.2	Incremental, absolute and with respect to Machine Reference Zero	6
2.2.1	Sample	7
2.3	Machine Reference selection and search	9
2.3.1	Home search sequence	9
2.4	Operation with tools	10
2.4.1	Tool Preset	10
2.4.2	Deleting all tool offsets	10
2.5	Special operations	11
2.5.1	Scaling factor	11
2.5.2	To access the special functions (Hold, taper calculation, calculator)	11
2.5.3	Coordinate freeze (HOLD)	11
2.5.4	Taper calculation	12
2.5.5	Calculator	13
2.5.5.1	Operating with the calculator.	13
2.5.5.2	Recall and Preset modes	14
3	DRO installation	15
3.1	Installation of the built-in model	15
3.2	Rear panel	16
3.3	General technical characteristics	17
3.4	Connections	17
3.4.1	Connection of the feedback systems	17
3.5	Easy setup	18
3.5.1	Accessing the "Easy Setup" mode	18
3.5.2	Operation mode.	18
3.5.3	Power and machine connection	19
3.6	Installation parameters	19
3.7	Parameters to configure axis position reading and display	21
4	Appendix	27
4.1	UL seal	27
4.2	CE seal	27
4.2.1	Declaration of conformity	27
4.2.2	Safety conditions	28
4.2.3	Warranty terms	30
4.2.4	Returning conditions	30
4.3	Error codes	30
4.4	Maintenance	32

1.1 Front panel

Each axis display has eight 14.1 mm high LEDs and another one for the minus sign (-).

Description of LED's and keys:



ABS It stays on when operating in absolute mode and off when in incremental mode. To access it or quit it, press this key.



Φ It stays on when operating in diameter mode. In this mode, the DRO displays twice the actual axis movement. To access it or quit it, use this key if allowed by installation parameter PAR04.



INCH It stays on when working in inches and off when doing it in millimeters. To access it or quit it, press this key.



To get into and out of home search mode.



Selection of the current tool.

There are 20 tools that may be set for the part when using absolute coordinates. The possible reference points (datum points) are from 0 to 19. The 20i-T model shows the active reference on the display at all times, whereas the 30i-T model only shows it when it is selected, after pressing the reference key.



To select the axis or preset it with a certain value.

To zero the axis when the "quick zeroing" mode has been activated (see PAR11 in the installation manual).



Only for 30i-T. Key to select whether the 2nd display corresponds to "Z₁", "Z₂" or to the "Z₁+Z₂" combination respectively. Every time this key is pressed, the rightmost digit of the 3rd display rotates from "1" to "2" and off respectively.



To turn the display off while keeping track of the axes position at all times.



To cancel or abort an operation already initiated.



To validate a preset value or another operation.

Beginning of preset when the "quick zeroing" mode has been activated (see PAR11 in the installation manual).



To change the sign of the entered value or change from fine to coarse resolution and vice versa.



To access the special functions (Hold, taper calculation).

1.2 Turning the unit on and off

It turns on automatically when applying voltage or after pressing the on/off key.

It shows **Fagor dro** or the corresponding error code. See the error table and PAR11 for more options.



Turns the DRO on or off.

Precautions



Before disconnecting this unit from mains, press this key so it saves the current position.



If the unit is turned off or there is a power outage, the DRO will try to save the current position. If it does not have enough time to save all the data, it will display ERROR 2 when turned back on.

2.1 Display modes

MM / INCH conversion



To display the position of the axes either in millimeters or inches by pressing this key depending on whether the INCH led is off or on respectively.

Fine / coarse resolution



To turn off the last decimal digit (coarse resolution) for cases in which fine resolution is excessive, simply by pressing this key.

Number of decimals



5

3

This keystroke sequence accesses parameter PAR53. The first digit corresponds to the number of decimals to be displayed in mm and the second digit in inches.

Radius / Diameter



When these models are used for measuring radii or diameters, one can display twice the real displacement of the axis (diameter) by pressing this key. The Φ led will turn on or off to indicate the double or actual reading respectively.

Notes: - This works in this way if bit 2 of installation parameter PAR04 (radius/diameter) of the axis has been preset as "1" (commutated).

Z axis as a single axis or combination of both (Z_1 and Z_2). Only at the 30i-T:

To display the Z axis position, one or two feedback devices may be used. One for the cross slide (Z_1) and the other one for the carriage (Z_2).

When using two feedback devices, the "Z" axis display may show the position of Z_1 , that of Z_2 or the result from combining (adding) the positions of both axes.



The rightmost digit of the third display shows a "1", a "2" or is off to indicate that the Z axis display (2nd one) corresponds to " Z_1 ", " Z_2 " or to the combination of " Z_1+Z_2 " respectively. This selection rotates by pressing this key. It also shows the text "tool" followed by the number of the active tool corresponding to the XZ coordinates shown on the other displays.

Axis feedrate. Only at the 30i-T:

The third axis (Zs) display shows the feedrate of the fastest moving axis in m/min or feet/min depending on the status of the "inch" LED. To activate or cancel this option, see PAR11 in the installation manual.

2.2 Incremental, absolute and with respect to Machine Reference Zero

This DRO shows the current position of two or three axes (20i-T / 30i-T).

Coordinate means the distance from one point or position with respect with another chosen as reference.

These DRO's can show the position of the axes in incremental or absolute mode.

- In **Home mode**, it displays the distance from the current position of the axis to the home point chosen in the feedback system.




Press this sequence to access the **Home mode** (only to search home).

(ABS) • In **Absolute (ABS)**, when the ABS led is on, it displays the distance from the present position of the axis to part zero (D).

(I) • In **Incremental**, when the ABS and "home" LEDs are off the distance from the present position of the axis to the previous position is displayed.



Toggles between the ABS and incremental modes.




It could occur that the installation parameter PAR11(1) has been set to "0" for this key to independently affect each axis so that one axis can display its position in incremental mode while the other does this in absolute. In this case, to change the display mode, press one of these two sequences.

2.2.1 Sample

Using the lower figure, let us imagine we wish to make a part in which three holes have to be drilled with the coordinates stated. It is clear that the blueprint will only reflect the incremental coordinates (I) or the absolute ones (ABS) referring to the part zero (point "0" in the figure) although the DRO also shows them with respect to home (lo).

After referencing the axes, as was described in the previous section, we can make this part in incremental or absolute mode according to whether we chose a type of dimensions (I) or (ABS) of the blue-print.

In incremental mode:



- Press this key until the ABS LED is turned off.



- Move the axis up to the face of the part to set it as part zero.

At this point, one can proceed in two ways:



- Preset the axis with a zero value by pressing this keystroke sequence:

[22.600]

- Move the axis towards the first position until the DRO reads: 22.600.

or...



[22.600]



- Preset the axis with a value of 22.600 by pressing this keystroke sequence.



In case of a mistake, press this key to cancel it and leave it as it was.



Pressing this key displays the previous preset value.

[0.000] - Move the axis towards the first position until the DRO reads: 0.000.

This last method turns out to be more practical as after selecting the destination coordinate one only has to remember to move the axis until the DRO reads zero.

[25.000] [0.000] - Once this turning operation has concluded, one can go to the next position, after having preset the next coordinate (25.000), by moving the axis until the display reads 0.000.
- And so on until all the turning operations are concluded.

Note:

ABS  By pressing this key until the **ABS** LED lights up, the DRO will show the real position of the axis with respect to part zero "0".


In absolute mode:

ABS  - Press this key until the **ABS** LED is turned on.

- To preset part zero:

- Place the axis exactly over "0" and press:

ABS  At any time, by pressing this key, the DRO will display the present position with respect with the previous zero (ABS led on).



2.3 Machine Reference selection and search

Although it is not absolutely necessary, it is recommended to use the reference marks (lo) of the feedback system in order to set a machine zero point.

This allows the user to reference the machine axes and restore the work coordinates after having turned the dro off, moved the machine while the dro was off, for safety or for any other reason.

Fagor linear encoders have reference marks every 50 mm all along its length.

In order to use these marks properly, choose an area on the axis, for example in the middle of the measuring length or at one end. Approach this area and carry out the home search. Once the reference mark has been found, mark this area with a marker or sticker in order to carry out the home search in the same area in later occasions and make sure that you are using the same machine zero point (home).

Fagor also offers encoders with distance-coded reference marks every 20, 40 or 100 mm. When using these distance-coded reference marks, there is no need to move to the 0 position to find the references, simply move a distance equal to the gap between marks (20, 40 or 100 mm depending on the linear encoder).

When using an absolute encoder, there is no need to search for the reference marks (home).

The dro stores in its internal memory work coordinates such as machine zero, absolute and incremental.

2.3.1 Home search sequence

For encoders with regular reference marks, move the axis to the home area.



Access or exit the home search mode.

The axis displays blink showing "r" if the axis has not been homed or "r on" if it has found the references (home).



Select the axis to be referenced (homed).

The selected axis blinks until a reference mark is detected. The reference signal presets the axis display automatically with the value of PAR10, 0.000 mm by default.



If the encoder does not have a reference mark, move the axis to the desired position and press this key.

2.4 Operation with tools

2.4.1 Tool Preset

Up to 20 tools may be preset on this DRO model (from "tool 0" to "tool 19"). The unit stores in its internal memory the relative offsets of all the tools with respect to that of "T0".

Therefore, if "T0" has been preset in **ABS** mode (on X and Z) and, then, the rest of the tools, it will suffice to just preset "T0" again (on Z) to make a new part. The DRO will then automatically recalculate all the offsets of the rest of the tools without having to preset them for each part.

To preset a tool, just follow this procedure:

ABS



- Place a part of known diameter in the chuck in absolute mode (ABS led on).
- Move the tool to be preset until it touches the part.



- Press this key. The 3rd display shows the word "tool" followed by the number of the active tool.

- Enter the tool number.



- Press **[ENTER]** to validate this operation or **[C]** to cancel it.



- Preset the part diameter.

These tool presets are kept in memory even when the unit is powered off up to a maximum of 10 years.

Notes: The presets done with any tool in incremental mode change the part zero for all the tools.

If a tool offset has been preset in Z_1 , Z_2 or Zs mode, that tool must be used in the same mode (Z_1 , Z_2 or Zs) when using it to machine the part.

The tool offsets are referred to the machine zero found at the time. When turning the DRO on, it is necessary to find the same reference mark.

The **calculator** function can also be used to preset an axis with the result of the calculation. See section 2.5.5 Calculator.

2.4.2 Deleting all tool offsets



To delete the offsets of ALL the tools. Press this keystroke sequence. It will show the text: "**Delete?**",



Press **[ENTER]** to validate the operation or **[C]** to cancel it.

2.5 Special operations

2.5.1 Scaling factor

It is possible to apply a scaling factor within ± 9.999 for mold making applications:



The DRO will then show the axis position resulting from multiplying its real position by the 'value' of the scaling factor.

2.5.2 To access the special functions (Hold, taper calculation, calculator)

 Press the [F] key to access the special functions menu.

This key may be used to display the various available options.

 Pressing [ENTER] assumes the selected option.

Options:

- 1 - HOLD
- 2 - Angle calculation (taper)
- 3 - Calculator

Note:

  A function may be directly accessed by pressing [F] and then the function number. That is, [F] [1] to access HOLD directly or [F] [2] for angle calculation.

2.5.3 Coordinate freeze (HOLD).

It enables "freezing" the display of the counter whilst it goes on reading the real position of the axis. This comes about when it is necessary to change the tool and preset the dimension of the new one.

Tool preset in HOLD mode.

It is possible to preset on the X axis the actual diameter value of the machined part (measured with caliper or micrometer).

Procedure:

Having selected a tool:

- Machine the part to any diameter.

   • Without removing the tool, set the X axis in HOLD mode.

- Remove the tool and measure the resulting diameter.

 **Value**  • Preset the part diameter. That value will be preset as the offset of the selected tool.

 • Exit the HOLD mode.

Tool change at any known point of the part:



- Touch the part with the tool.
- Go into HOLD mode. The reading for that axis freezes with the current value.

- Remove the tool to be replaced and insert the new one.

- Approach the new tool to the "freezing" point and touch the part at that point.



- Press this key. The reading "unfreezes" and starts counting from the previously "frozen" value.



- If this key is pressed instead, the DRO will assume half the distance traveled since the [HOLD] key was pressed. This is possible when "freezing" only one axis.

2.5.4 Taper calculation



This DRO calculates the taper angle (cone) of a part by simply touching two of its points and using these keys.

To do this, follow this procedure:



- Move the tool until it touches the part at any point of the taper.
- Access the angle calculation mode.


- Touch the part with the tool at any other point of the taper.



- Press [ENTER] so the DRO calculates the angle or [C] to cancel the operation.

The "X" axis display will show the angle in ten-thousandths of a degree (0.0001°) and the "Z" axis display will do so in degrees, minutes and seconds.

- Press any key to return to the regular display mode.



2.5.5 Calculator

This feature may be used to carry out mathematical and trigonometric operations as well as preset the desired axis with the result of the calculation or use the coordinates of the axes to carry out math operations.



3

To access the calculator mode.



To quit the calculator mode.

2.5.5.1 Operating with the calculator.



Enters the first operand in the X axis display.



Enters the second operand in the Z axis display.



Toggles between the various operations:

Basic operations

Display	Meaning	Operation
ad	Add	Result = X + Z
su	Subtract	Result = X - Z
nu	Multiply	Result = X * Z
di	Divide	Result = X / Z



Toggles between the various trigonometric operations:

Trigonometric operations

Display	Meaning	Operation
Sin	Sine	Result = Sin X
Cos	Cosine	Result = Cos X
Tan	Tangent	Result = Tan X



It carries out the operation and leaves the result on the X axis display.

2.5.5.2 Recall and Preset modes



Toggles between the recall and Preset modes.

RECALL mode The recall mode lets enter the current axis position into the calculator.



Enters the current position of the selected axis into the calculator. The **[Z]** key for the Z_1 axis and the **[Zs]** key for the Z_2 axis.

PRESET mode The preset mode lets preset the desired axis with the result of an operation.



Presets the selected axis with the result of the calculation. The **[Z]** key for the Z_1 axis and the **[Zs]** key for the Z_2 axis.

Sample Calculate **[Z₁ position]** / 5 and **preset the Z** axis with the result.


Example: calculator

Display	keys	operation	Display
X = 25 Z = 10		Goes into calculator mode	X = 0 Z = 0 Z _s = Ad
X = 0 Z = 0 Z _s = Ad		Goes into RECALL mode and enters the current position in the Z axis.	X = 10 Z = 0 Z _s = Ad
X = 10 Z = 0 Z _s = Ad	5	Presets the divisor (5)	X = 10 Z = 5 Z _s = Ad
X = 10 Z = 0 Z _s = Ad	3 times	Selects the divide operation	X = 10 Z = 5 Z _s = di
X = 10 Z = 5 Z _s = di		Result in the X display (2)	X = 2 Z = Z _s = di
X = 2 Z = Z _s = di		Goes into Preset mode	X = 2 Z = Preset Z _s =
X = 2 Z = Preset Z =		Presets the Z_1 axis with the result of the calculation.	X = 25 Z = 2 Z _s = di
X = 25 Z = 2 Z _s = di		Quits the calculator mode.	X = 25 Z = 2 Z _s =


3 DRO installation

3.1 Installation of the built-in model


Dimensions of the enclosure hole for inserting the DRO



Built-in DRO insertion



3.2 Rear panel



On the back of the unit the following items may be found:

1. Three-prong power connector for AC and ground connection.
2. M6 mm terminal for general machine ground connection.
3. Mounting bracket

Some of the following connectors might not be available depending on specific models:

- X1.- SUB-D HD type 15-pin female connector for 1st axis feedback device.
- X2.- SUB-D HD type 15-pin female connector for 2nd axis feedback device.
Not available at the 10i model.
- X3.- SUB-D HD type 15-pin female connector for the third axis feedback device.
Only available at the 30i-M model.

UL seal



In order to comply with "UL" standards, this unit must be connected in the final application using a listed detachable cord set (BLEZ) with a molded three-prong plug and a suitable fitting to be connected to the equipment, rated minimum 300 V AC. The cord type shall be SO, SJO or STO. Suitable Strain Relief means must be provided in the cord set to assure the connection of the plug and the fitting.

CE seal (see "CE seal" on page 27)

WARNING



Do not handle the connectors while the unit is under power.

Before handling the connectors (mains, feedback, etc.) make sure that the unit is not under power.

It is NOT enough to turn the display off by using the [on/off] key at the keyboard.

3.3 General technical characteristics


- Universal Power Supply between 100 V AC and 240 V AC $\pm 10\%$ at a mains frequency between 45 Hz and 400Hz, between 120V DC and 300 V DC. Maximum power consumed 20 VA.
- It withstands power outages of up to 20 milliseconds.
- 10-year memory backup of installation parameters when the unit is off.
- The operating temperature inside the DRO enclosure must be between 5° C and 45° C (41° F and 113° F).
- The storage temperature inside the DRO enclosure must be -25° C and +70° C (-13° F and 158° F).
- Maximum relative humidity: 95% non condensing at 45° C (113° F).
- Front Panel Sealing: IP54 (DIN 40050), Rear panel: IP4X (DIN40050) except for built-in models in which case is: IP20.

3.4 Connections

3.4.1 Connection of the feedback systems

The feedback systems (linear or rotary encoders) are connected via SUB-D HD type 15-pin female connectors: X1 through X3. The latter (for the 2nd axis) is not available at the 10i model.

Characteristics of feedback inputs: X1, X2 and X3:



- Power consumption: 250 mA at the +5 V input.
- Admits square-wave signal (TTL). (A, B, Io).
- Maximum frequency: 250 kHz, minimum gap between flanks: 950 ns.
- Phase shift: $90^\circ \pm 20^\circ$, hysteresis: 0.25 V, Vmax: 7 V, maximum input current: 3 mA.
- High threshold (logic state 1): $2.4 \text{ V} < \text{VIH} < 5 \text{ V}$
- Low threshold (logic state 0): $0.0 \text{ V} < \text{VIL} < 0.55 \text{ V}$

Feedback connection. Connectors X1, X2 and X3

Pin	Signal	Function
1	A	Input for feedback signals
2	/A	
3	B	
4	/B	
5	IO	
6	/IO	
7	Alarm	
8	/Alarm*	
9	+5V	Power supply to feedback devices
10	Not connected	
11	0V	Power supply to feedback devices
12, 13, 14	Not connected	
15	Chassis	Shield

3.5 Easy setup.

The "Easy Setup" may be used to set up the feedback of the DRO and to verify that the installation is correct and no feedback pulses are missed.

It sets up the encoder resolution and the kind of reference marks being used as well as the positive counting (reading) direction.

3.5.1 Accessing the "Easy Setup" mode



Press **[CLEAR] [OFF]**.

CODE:555 And, instead of entering the parameters accessing code, key in: **555**

The axes displays will show "**Setup**" meaning that the feedback is not set up yet.

3.5.2 Operation mode.

- Move the axis to the origin or zero point and press the axis key.
The display shows "**START**".
- Move the axis in the positive direction all the way to the end of the travel so the DRO can read as many reference marks as possible.
- Press **[ENTER]** to finish. The moving direction used will be assumed as the positive direction.



The axis status will then switch to one of the following:

Ready Feedback configured properly.

Repeat Wrong feedback setup, the process should be repeated.

Error Error in the feedback system.

Note: If the feedback device is a steel tape type linear encoder, press **[F]** before pressing **[ENTER]** so it is properly detected.

3.5.3 Power and machine connection

Always mount it vertically so its keyboard is within operator's reach and its digits are easily visible (at operator's eye level).

Do not connect or disconnect the DRO connectors while it is under power.

Connect all metallic parts to a common point on the machine tool and it to the general ground point. Use cables of enough gage (no thinner than 8 mm²) for this connection.

3.6 Installation parameters

These DROs have a number of installation parameters to configure it for a particular application.

The way these parameters are displayed depends on whether they are general or particular for each axis.

- If it affects the axes, the parameter number (PAR??) appears on each axis display and the corresponding axis key must be pressed to modify it.



- If it is a general parameter, the X display will show the parameter number and the Z its current value; if there is only one axis, its number will appear on the X display and, after pressing, its value.

There are several kinds of parameters depending on how to set them:



to



- With binary values, it only admits values of 0 or 1 for each digit. The value is changed by pressing the key with the relevant digit between [1] and [8]. Where [1] corresponds to the rightmost digit of the display and [8] to the leftmost digit.
- Numeric values, usually with the corresponding axis resolution, they are entered as regular coordinate preset.



- Options; the value is changed by pressing this key which will make the various options appear in a cyclic way.

To get into parameter editing



The dro displays must be on, reading mode and press the following keys:

CODE: 060496 The X axis display shows the word "COdE". 060496

The displays of the DRO show **PAR00**.



Once in regular display mode, parameter **PAR05** (scaling factor) may also be recalled by pressing this keystroke sequence, so the work mode may be changed without having to go through all the previous steps.

Note: Like PAR05, parameter PAR53 is directly accessible.

To enter a parameter



• Select axis.



• Press this key to save the displayed value.



• Press this key to cancel the modification.

Move through parameters



Press the **[ENTER]** key to go on to the next parameter or...



Press this key to return to the previous one.

To quit the parameter editing mode:



Press the key.

To go to a particular parameter:



To go directly to a particular parameter without going through the previous ones, (once in parameter editing mode) press this key sequence.



Then, select the axis affecting this parameter.

To recover the factory set default values for the installation parameters:



Once in parameter editing mode, **displaying PAR00** on all the displays, press this keystroke sequence. The dots of the first axis will light up.

3.7 Parameters to configure axis position reading and display.

The digits of digital parameters refer to the digits on the axis displays so digit "1" (that can be changed with the [1] key) corresponds to the rightmost digit and "8" to the leftmost digit.

X X X X X X X X X <- binary code
8 7 6 5 4 3 2 1 <- keys

PARAMETER	MEANING
PAR00	Feedback configuration, different per axis, binary type. This parameter sets the specific characteristics of the feedback device (rotary or linear encoder) used to read the axis position.
Digit	
8, 7, 6	Not being used at this time (they must be set to "0").
5	Feedback resolution units: Linear axis: 0 = mm, 1 = inches
	Note: These units refer to feedback pulses not to the position display.
4	Type of axis: They must be set to zero.
3	Not being used at this time.
2	Not being used; it must be set to "0".
1	Counting direction (0 = normal, 1 = reverse). If an axis count increases or decreases in the opposite direction to the one desired, change the value of this digit.
PAR01	Feedback resolution. Independent for each axis. Possible values: Linear axis: from 0.0001 mm up to 1.0000 mm (0.000005" to 0.03937"). Rotary axis: from 0.0001° to 1.0000° (from 1 to 999 seconds). Factory setting: 0.0050 mm (5 µm).
	Formula to calculate encoder resolution:
	$R = \frac{360}{p \times TTLfactor} = \frac{360}{p \times PAR02}$
	Where: R = Resolution in degrees p = Pulses per turn of the encoder TTLfactor = Multiplying factor for TTL signal

PAR02**TTL multiplying factor (subdivision).** Independent for each axis.**Options:** x4, x2, x1 and x0.5.

The factory setting is x4 and it is the one used for FAGOR linear encoders.

When using rotary encoders on linear axes, it should be calculating according to the number of pulses of the encoder, leadscrew pitch and the desired resolution as per the formula:

$$p = \frac{P}{RxF}$$

Where:

p = Pulses per turn of the encoder**P** = Leadscrew pitch in mm/turn**R** = Resolution in mm/pulse**F** = Multiplying factor to be applied**PAR03****External multiplying factor** when using distance-coded reference marks or TTL signals.

Independent for each axis. It is not required when using absolute feedback.



Options: 1, 5, 10, 20, 25, 50.

Factory setting: 1**Feedback parameters**

Signal	Model	PAR00 XXXXXXXX	PAR01 mm	PAR02	PAR03	PAR14
TTL	MT / MKT CT FT		0,005			
TTL dif.	MTD	0000000X	4	X	00X0XX00	
	MX / MKX					
	CX		0,001	5	00X00010	
	SX					
	GX					
	FX			25	00X01010	
	LX					
	MOX		10	10	00X00110	
	COX					
	SOX					
	GOX					
	FOX					
	LOX					

Note: In the table, X means that the bit is irrelevant.

PAR04	Axis display. Independent for each axis.
Digit	
8, 7, 6, 5, 4, 3	Not being used at this time (they must be set to "0"),
2	Axis display toggle radius/diameter 0 = no toggle, 1 = toggle
1	Axis display. 0 = radius, 1 = diameters. When it does not toggle.
PAR05	Shrink or scaling factor independent for each axis. Numeric value within ± 9.999 . A "0" value means that no factor is to be applied. It is not applied when reading with respect to machine reference zero (its LED on) or onto the tool when applying tool compensation (TOOL led on). The factory setting is "0".
PAR08	Use of alarms. Indicates whether the alarms for feedrate, travel limits and feedback will be activated or not.
Digit	
8, 7, 6, 5	Not being used at this time (they must be set to "0").
4	Active value of the feedback alarm. (0=low, 1=high).
3	Detect feedback alarm provided by the scale. 0 = No, 1 = Yes.
2	Detect travel limits (PAR12 and PAR13). When this alarm is activated, the axis value blinks. The blinking axis error is cleared by returning the axis within its limits
1	Detect feedback speed alarm when the feedrate exceeds 200 KHz (60 m/min with 1 μ m resolution). Not applicable to a rotary axis. Possible values: 0 (alarms off) and "1" (alarms on). Factory values: 0 Feedback and feedrate alarms are shown with (.....) at the display.
	The speed alarm is cleared by pressing this key.
PAR09	Linear compensation of a machine axis. Independent for each linear axis. Numeric value within ± 99.999 millimeters per meter. Factory setting: 0.
Notes:	Even when selecting the display in inches, this value MUST ALWAYS BE IN MILLIMETERS. 1 inch = 25.4 mm When a rotary axis, the setting of this parameter will be ignored.
PAR10	Offset of the reference point with respect to the reference zero of the feedback device, independent for each axis.

Usually, the machine reference zero (reference mark of the linear encoder) does not coincide with the absolute zero to be used.

Therefore, when using standard lo's, this parameter must be assigned the value of the distance from the machine zero point to the feedback reference point.

Numeric value in resolution units for each axis.

Factory setting: 0.

This value will be in mm or inches depending on whether the INCH LED is off or on.

PAR11

Digit

- 8 Display the feedrate of the moving axis (only for the 30i-T).
- 7 Operate always in mm.
- 6 Operate always in inches.
- 5 Do not display "Fagor DRO" on power-up.
- 4 If =0, normal zero setting and coordinate presetting (factory set).
If =1, quick zeroing of the position value displayed on each axis.
- 3 If =1, allow the selection of the work plane for bolt-hole drilling
- 2 Not being used; it must be set to "0".
- 1 The key affects one axis (= 0) or both (= 1). 

If it affects each axis independently, after pressing this key, one must press the axis key.

It may toggle from absolute reading mode to incremental. This parameter determines whether this toggle affects one axis or both. **Factory setting: "1".**

PAR12, PAR13

Travel limit.

To set the negative axis travel limit.

Both parameters admit any value.

This value will be in mm or inches depending on whether the INCH LED is off or on.

If PAR08 bit 2 = 1, when the axis exceeds the travel distance between both parameters, the relevant display starts blinking until it is positioned within these limits.

PAR14


Binary type home search setting.

Digit

- 8, 7 Not being used at this time (they must be set to "0").
- 6 If =1, it indicates **mandatory home search on power-up**.
- 5 **Direction of the distance-coded lo.** (0 = Increasing, 1 = Decreasing).
- 4 **1 = Pitch of the distance-coded lo 100 mm, 0 = 20 mm**
- 3 **1 = Pitch of the distance-coded lo: 40 mm. 0 = 20 mm**
- 2 **Type of lo of the linear encoder.** (0 = fixed, 1 = distance-coded).
- 1 If =1, **Linear encoder without lo.** To carry out a home search when the feedback device does not have a reference mark "lo", this parameter must be set to "1".

Factory setting: "0".

Important: Before capturing data for an accuracy graph, a home search must be carried out because the compensation will not be applied until the home search is done. To use this compensation, it is recommended to set **PAR 14** so as to force a mandatory home search on power-up.



The compensation point must have at least one point with no error (error 0).

Multi-point leadscrew error compensation table (in mm)

Point Nr.	Position	Error to be compensated
1	0	0
2	200,000	0,002
3	275,250	0,007
4	427,345	-0,005
5	700,500	-0,007
6	760,000	0,003
7	1015,000	0,006

Note: The compensation table is always written in millimeters. Multipoint compensation can only be applied to linear axes, it is not valid for angular axes.

  or  Select the desired axis and enter the number of points to be used for this axis, up to 40; zero means that there is no compensation table for the axis.

POS 1 Where "POS 1" is the point number to enter and "ERROR 1" the amount of error to be compensated.



Pressing [ENTER] displays the position value (X axis display) and the amount of error to be compensated (Z axis display).



[Pos Nr]



Error to be compensated = Master's actual position - displayed position



[Error]



It goes on to edit the next point.

PAR20 It sets the configuration of the axes.

Digit

8

Turn the feedback off after 2 minutes in "DISPLAY OFF" mode.

7

The displays turn off if none of the axis has moved in 30 minutes. When pressing a key or moving one of the axes, the DRO turns the displays back on.

6 - 1

Not being used at this time. They must be set to "0".

PAR53 Select the number of decimals to be displayed.

Possible values: 0.0 to 6.6.

The first digit corresponds to the number of decimals to be displayed in mm and the second digit to the number of decimals in inches.

When selecting a "0" value or a value greater than the number of decimals of **PAR01** it will display the factory set number of decimals.

Note: It has no effect on rotary axes.

PAR65 It enables various functions of the dro.

Digit

8, 7, 6

Not being used at this time.

5

1= To directly access parameter PAR05.

4

Not being used at this time.

3

1= Enables the buzzer. It beeps when pressing any key.

2



To access the special functions (Hold, taper calculation).

1



It enables this key.

4.1 UL seal

See "UL seal" on page 16.

4.2 CE seal

Warning



Before starting up the DRO, carefully read the instructions of Chapter 2 in the Installation Manual.

The DRO must not be powered-on until verifying that the machine complies with the "89/392/CEE" Directive.

4.2.1 Declaration of conformity

The declaration of conformity for the DRO is available in the downloads section of FAGOR'S corporate website at <http://www.fagorautomation.com>. (Type of file: Declaration of conformity).

4.2.2 Safety conditions

Read the following safety measures in order to prevent harming people or damage to this product and those products connected to it.

Fagor Automation shall not be held responsible of any physical or material damage originated from not complying with these basic safety rules.

Do not manipulate the inside of the unit



Only personnel authorized by Fagor Automation may access the interior of this unit.

Do not handle the connectors with the unit connected to main AC power



Before handling the connectors (mains, feedback, etc.) make sure that the unit is not under power.

Use proper Mains AC power cables

To avoid risks, use only the Mains AC cables recommended for this unit.

Avoid electrical overloads

In order to avoid electrical discharges and fire hazards, do not apply electrical voltage outside the range indicated in chapter 2 of this manual

Ground connection

In order to avoid electrical discharges, connect the ground terminals of all the modules to the main ground terminal. Before connecting the inputs and outputs of this unit, make sure that all the grounding connections are properly made.

Before powering the unit up, make sure that it is connected to ground

In order to avoid electrical discharges, make sure that all the grounding connections are properly made.

Ambient conditions

Respect the temperature and humidity ranges specified in the chapter "General technical characteristics" on page 17.

Do not work in explosive environments

In order to avoid risks, harm or damages, do not work in explosive environments.

Work environment

This unit is ready to be used in Industrial Environments complying with the directives and regulations effective in the European Community.

It is recommended to mount the DRO vertically,

so its power switch of the back panel is at a distance between 0.7 m (27.5 inches) and 1.7 m (5.6 ft) off the floor and away from coolants, chemical products, blows etc that could damage it. Keep it away from direct sunlight, extremely hot air, high voltage and high current sources as well as from relays, or high electromagnetic fields (about 0.5 m or 20 inches).

This unit meets the European directives on electromagnetic compatibility. Nevertheless, it is recommended to keep it away from sources of electromagnetic disturbance, such as:

- Powerful loads connected to the same AC power line as this equipment.
- Nearby portable transmitters (Radio-telephones, Ham radio transmitters).
- Nearby radio / TC transmitters.
- Nearby arc welding machines.
- Nearby High Voltage power lines.
- Disturbance generating elements of the machine.
- Etc.

Safety symbols

Symbols that may appear in the manual.



WARNING symbol.

It has an associated text indicating those actions or operations may hurt people or damage products.

Symbols that the product may carry

WARNING symbol.



It has an associated text indicating those actions or operations may hurt people or damage products.

“Electrical shock” symbol.



It indicates that that point must be under voltage.

“Ground Protection” symbol.



It indicates that point must be connected to the main ground point of the machine as protection for people and units.

4.2.3 Warranty terms

The warranty conditions for the DRO are available in the downloads section of FAGOR's corporate website at <http://www.fagorautomation.com>. (Type of file: General sales-warranty conditions).

4.2.4 Returning conditions

When returning the DRO, pack it in its original package and with its original packaging material. If you do not have the original packaging material, pack it as follows:

Get a cardboard box whose 3 inside dimensions are at least 15 cm (6 inches) larger than those of the unit itself. The cardboard being used to make the box must have a resistance of 170 Kg (375 lb.).

When sending it to a Fagor Automation office for repair, attach a label indicating the owner of the unit, person to contact, type of unit, serial number, symptom and a brief description of the problem.

Protect the unit wrapping it up with a roll of polyethylene or with similar material.

Pad the unit inside the cardboard box with polyurethane foam on all sides.

Seal the cardboard box with packaging tape or with industrial staples.

4.3 Error codes

Error codes

Error	Description
FAGOR dro	Power outage or turned off with main switch after saving the data.
Error 02	The unit has been turned off without previously pressing [ON/OFF]. It only loses feedback reading (it resets it to zero and the status of the operating modes, inch, abs, radius, etc.).
Error 04	Wrong parameter data
Error 05	Wrong internal configuration
Error 06	Errors in data backup memory (Service Dept.)
Error 07	Emergency input active. Press [CLEAR] or cancel the emergency signal.
Error 08	Wrong software memory or the software has been changed.
Error 09	Errors in work memory (Service Dept.)
Error 12	Error while searching a distance-coded reference mark (lo).
Error 31	Internal malfunction (Service Dept.).
Error 32	Internal malfunction (Service Dept.).
Error 99	Internal malfunction (Service Dept.).
.....	Feedback alarm coming from the feedback device (linear or rotary encoder).
1. 4. 3. 6. 5. 7. 2. 5	Feedback speed too high.
EEEEEEEEE	Maximum position reading or speed exceeded when searching home.

If any message other than the first two from the table were to come up, the equipment should be switched off and on again until one of the first two are seen.



After pressing this key to access the counting mode, check the parameters.

If any of the errors shown as (Service Department) are often repeated, ask Fagor Automation's Customer Services Department about this.

If the display of any axis shows all its dots; for example: 1.4.3.6.5.7.2.5. means that the axis has moved at a greater speed than what is required for its reading (>200 kHz or 60 m/min with 1 μ m resolution). This error will be displayed if the alarm activation parameter for the axis PAR08(1)=1.



To clear the display, press this key.

If the axis value is flashing, this means that one of the travel limits established by machine parameter has been exceeded. This error will be displayed if the alarm activation parameter for the axis PAR08(2)=1.

If the DRO does not come on or goes out while running, check that the voltage and ground outlets are as they should be. If there are OK, disconnect the feedback connectors one by one. If the dro comes on, it means a feedback failure. If the fault persists get in touch with Fagor Automation's Customer Services Department about it.

4.4 Maintenance

Cleaning: An accumulation of dirt in the equipment can act as a screen preventing proper dissipation of the heat generated by the internal electronic circuits with the consequent danger of overheating and DRO fault.

On the other hand, accumulated dirt can sometimes act as an electrical conductor and shortcircuit the internal circuitry, especially under high humidity conditions.

To clean the unit, we recommend to use non-abrasive dishwasher detergent (gel, never powder) or isotropic alcohol at 75% with a clean cloth. DO NOT USE aggressive solvents, (benzol, acetones, etc.) which could damage the materials the equipment is made with.

Never use air compressed at high pressure to clean the unit because it could cause the accumulation of electrostatic charges that could result in electrostatic shocks.

The plastics used in the front panel of the DRO stand up to:

- Grease and mineral oils.
- Bases and bleach.
- Dissolved detergents.
- Alcohol.

Avoid the effect of solvents such as Chlorohydrocarbons, Benzol, Esters and Ethers because these could damage the plastics with which the front of the equipment is made.

Preventive If the DRO does not come on press the rear switch for starting, make sure it is **inspection** properly connected and being supplied with the proper mains voltage.

FAGOR AUTOMATION S. COOP.

B^a San Andrés Nº 19

Apdo de correos 144

20500 Arrasate/Mondragón

- Spain -

Web: www.fagorautomation.com

Email: contact@fagorautomation.es

Tel.: (34) 943 719200

Fax: (34) 943 791712

